

MICROWAVE RICE COOKER



The quickest and easiest way to cook rice is with a microwave rice cooker. This gives you an ideal result in terms of appearance and taste in just 10-13 minutes. Now it's all about the right rice/water ratio. Nothing can go wrong with this overview. Simply print it out, hang it on the fridge and start cooking. **Bon Appetit from Reishunger!**

REISHUNGER



	Rice	Water	Cooking time*
 BASMATI RICE	1	: 1,5	10-13 Min
 SUSHI RICE	1	: 1,5	10-13 Min
 SADRI RICE	1	: 1,5	10-13 Min
 JASMINE RICE	1	: 1,5	10-13 Min
 STICKY RICE (soak 4-12 hours)	1	: 2	10-13 Min
SADRI DUDI RICE	1	: 1,5	10-13 Min

INSTRUCTIONS

Use the measuring cup included in the set and enter the desired quantity of rice. One cup of rice filled up to the edge is enough for 2 portions. Now place the rice in the pot and thoroughly wash it twice. Do so by pouring cold water into the pot and washing the rice well with your fingers. Dump the cloudy water and now pour 1.5 times the water using the cup and add a pinch of salt. Close the rice cooker and place it in the microwave. Close the rice cooker and put it in the microwave at 750-800 watts. After approx. 11-13 minutes, the rice is done.

PLEASE NOTE:

The microwave rice cooker is mainly suitable for white (hulled) rice varieties such as Basmati rice, Jasmine rice or Sticky rice and is not suitable for rice varieties such as whole-grain-basmati or brown rice. In this case, we recommend that you cook with a conventional pot. Each microwave has different temperature settings. As such, make sure that you repeatedly check the water level in the pot during the 12 minute cooking process when using this product. The pot must always contain water, since otherwise the rice can burn, and the pot can melt.

We do not recommend preparing other types of rice in our rice cooker.

*The cooking time refers to 2 servings. All times are guidelines.

